

MOUNTING PROCEDURE

KIT WINDSHIELD HONDA HORNET 600 '07 - '10

HN6300-07

WWW.BARRACUDAMOTO.COM

KIT

- X1. SPECIFIC BRACKET
- X1. WINDSHIELD/SCREEN
- X4. SCREW 5X12
- X4. RUBBER WASHER
- X4. TEFLON WASHER DIAMETER 5 MM
- X4. LARGE WASHER DIAMETER 5MM
- X4. AUTOLOCK NUT DIAMETER 5



REMOVE THE HEADLIGHT-COVER UNLOCKING THE TWO SCREWS ON THE SIDE



REMOVE THE CENTRAL FIXING SCREW OF HEADLIGHT AND LOOSEN THE TWO SCREWS ON THE SIDES



INSERT THE SPECIFIC BRACKET BETWEEN THE HEADLIGHT AND THE INSTRUMENTATION. LOCK THE SCREWS MOUNTED BEFORE



MOUNT THE WINDSHIELD/SCREEN ON THE SPECIFIC BRACKET WITH THE INSTALLATION KIT INCLUDED :

- SCREW 5X12
- RUBBER WASHER
- TEFLON WASHER DIAMETER 5 MM
- LARGE WASHER DIAMETER 5MM
- AUTOLOCK NUTS DIAMETER 5



TAKE OFF THE HEADLIGHT REMOVING THE SCREWS ON THE FIXING SIDES. REMOVE THE SCREW BETWEEN THE HEADLIGHT AND INSTRUMENTATION, UNLOCKING THE FIXING SCREWS OF HEADLIGHT. INSERT THE SPECIFIC BRACKET BETWEEN THE HEADLIGHT AND THE INSTRUMENTATION, FIX ALL WITH THE CENTRAL SCREW TAKE OFF BEFORE AND LOCK AGAIN ALL THE SCREWS OF HEADLIGHT MOUNTING THE HEADLIGHT-COVER. MOUNT THE BARRACUDA WINDSHIELD/SCREEN ON THE BRACKET USING THE RUBBER WASHERS BETWEEN THE BRACKET AND THE PLEXIGLASS, WHILE THE TEFLON WASHERS BETWEEN THE HEAD OF SCREW AND THE PLEXIGLASS. PUT THE 4 SCREWS AND LOCK.